

Fuel System

Item No.	Part No.	Quantity	Description	Notes	Item No.	Part No.	Quantity	Description	Notes
			PETROL FILTER		+1574	52313	1	Bracket	
*1530	J54436	1	Petrol Line Filter		+1575	52314	1	Spring Arm	
*1531	J54562	2	Union		+1576	52315	1	Cross Rod Eye	
*†1532	J54436/1	1	Petrol Filter Cork Gasket						
			CHOKE CONTROLS					THROTTLE CONTROLS	
*†1535	50983	1	Choke Operating Rod Assembly		+1585	J54423	1	Throttle Rod Assembly	
*†1536	50887	1	" " Wire—L.H.		*1586	J54421	1	" " —Long	
*†1537	50888	1	" " —R.H.		*1587	J54422	1	" " —Short	
†1538	51398	1	" Control		*†1588	J54419	1	" " —Clamp Bolt	
			ACCELERATOR ASSEMBLY—R.H.D.		*1589	1-53712	1	Spring Plate	
†1542	50938	1	Accelerator Pedal		*1590	52076	1	Throttle Rod Spring	
†1543	52081	1	" " Spring					CARBURETTORS	
*†1544	50943	1	" Pivot Bolt		+1595	52396	1	Carburettor—R.H.	
†1545	52066	1	" Follower Assembly		+1596	52395	1	" —L.H.	
†1546	52068	1	" Follower Spacer		+1597	52396R	1	Reconditioned Carburettor—R.H.	
†1547	50944	1	" Cable Outer Case		+1598	52395R	1	" —L.H.	
†1548	54353	1	" Cable		†1599	06100	2	Banjo Union Filter Gauze	
†1549	52090	1	" " Tube—Long		†1600	06098	2	" " Fixing Plug	
†1550	52089	1	" " —Short		†1601	06101	4	" " Fibre Washer	
†1551	54352	1	" " Adjuster Clamp		†1602	010234	2	Carburettor Bowl to Barrel Gasket	
†1552	54351	1	" " Clamp		†1603	09865	2	Air Regulating Screw	
†1553	54350	1	" " Pivot		†1604	09846	2	" " Spring	
			ACCELERATOR ASSEMBLY—L.H.D.		†1605	07860	2	Progression Jet	
†1563	50937	1	Accelerator Pedal		†1606	06605	2	Main Jet (90)	
†1564	52081	1	Pedal Spring		†1607	16709	2	" " Fibre Washer	
†1565	52319	1	Lever Assembly		†1608	06620	2	Compensating Jet (50)	
†1566	52316	1	Link		†1609	16828	2	" " Fibre Washer	
†1567	52310	1	Cross Rod		†1610	06798	2	Slow Running Jet (45)	
†1568	52369	1	Cable Outer Case		†1611	06983	2	" " Washer	
†1569	J54420	1	Cable		†1612	08898	2	Float	
†1570	52076	1	Throttle Spring		†1613	06036	2	Needle Seating (1.5 mm.)	
†1571	52307	1	Accelerator Rod Assembly		†1614	09729	2	" " Washer	
†1572	52308	1	" Rod		†1615	07358	2	Throttle Spindle	
†1573	52312	1	Cross Rod Bracket		†1616	05923	2	" Stop Screw	
					†1617	04611	2	" Spring	

* Denotes items common to Jupiter

Always quote engine, body-frame, part and item numbers in full.

† Denotes items not illustrated