

DRILL 4 HOLES  $\frac{1}{2}$ " (5.56 mm) DIA. TO SUIT  
STANDARD REAR NUMBER PLATE PT. No. 51032  
AND FIT IN POSITION SHOWN.

REMOVE LAMP FROM REAR NUMBER PLATE BOX  
DRILL 3 HOLES  $\frac{1}{2}$ " (4.7625 mm) DIA. TO SUIT AND  
FIT IN POSITION SHOWN. USE EXISTING LEAD  
FROM REAR NUMBER PLATE LIGHT.

$\frac{1}{2}$ "  
(12.750 mm)

RUBBER WASHER PT. No. 51050

IF REQUIRED BUMPER OVERRIDERS (PT. No. 51421) MAY BE  
OBTAINED FROM JOWETT CARS LTD. SPARES DEPT.

SKETCH SHOWING POSITION OF REAR NUMBER PLATE AND LIGHT  
WHEN FITTING TOW BAR TO 1951 DELUXE MODELS.

