

Electrical Equipment and Instruments

Item No.	Part No.	Quantity	Description	Notes	Item No.	Part No.	Quantity	Description	Notes
*†2562	54035	2	Trafficator Movement		†2622	50819	1	Speedometer Cable—R.H.D.	
*†2563	581175	2	.. Arm		†2623	52375	1 —L.H.D.	
			HORNS AND PUSH MECHANISM		†2624	JB51696	1	Multiple Instrument comprising Oil Pressure, Water Temperature and Petrol Gauges	
†2570	50793	1	Horn—Low Tone—Standard and De-luxe (Lucas No. 69011)					De-luxe	
†2571	51343	1	Horn High Tone—De-luxe (Lucas No. 69012)		†2630	JB51823	1	Speedometer with Ignition Warning Light (miles)	
†2572	51566	1	.. Push, Standard		†2631	JB51824	1 " " " " (metric)	
2573	JB51703	1 De-luxe		†2632	50819	1	.. Cable—R.H.D.	
†2574	54025	1	.. Relay (Lucas SB40)		†2633	52375	1 —L.H.D.	
†2575	51611	1	Fuse Box (complete with 2-35 amp. fuses)		†2634	JB51737	1	Electric Time Clock	
†2576	50580AS	1	Horn Slip Ring Assembly		†2635	JB51739	1	Petrol Gauge	
			WINDSCREEN WIPERS		†2636	JB51740	1	Temperature Gauge	
†2580	50795	1	Screen Wiper Motor (Lucas No. 75055)		†2637	JB51741	1	Ammeter	
†2581	738560	1 End Cover—Bakelite		†2638	JB51738	1	Oil Gauge	
†2582	729367	1 Brush Set		†2639	JB51735	1	Cigar Lighter	
†2583	736012	1 Armature					OIL PRESSURE INDICATOR PIPES	
†2584	736010	1 Crosshead and Rack					De-luxe and Standard	
†2585	72590	1 Clutch Housing		*†2645	52709	1	Oil Pipe Assembly	
†2586	73754	2 Arm		†2646	52700	1 to Pressure Gauge—Long	
†2587	54048	2 Blade		*†2647	52707	1 " " " " —Short	
			VOLTAGE CONTROL BOX		*†2648	52706	1	Flexible Connection	
†2590	52557	1	Voltage Control Box (Lucas No. 37068)		*†2649	52699	1	Union	
			INSTRUMENTS AND FITTINGS		*†2650	50641	3	Olive Nipple	
†2620	JB51695	1	Speedometer with Ignition Warning Light (miles)		*†2651	ND1624	2	Nuts—Rotherham Type	
†2621	JB51789	1 " " " " " (metric)						

Tools

Item No.	Part No.	Quantity	Description	Notes	Item No.	Part No.	Quantity	Description	Notes
			TOOLS		*†2691	ND1062	1	Wheel Brace	
†2681	51453	1	Tool Roll (Standard only)		*†2692	51064	1	Starting Handle	
*†2682	52291	1	Sparking Plug Spanner		*†2693	ND393	1	Grease Gun	
*†2683	52024	1	Drain Plug Key (Gearbox)		*†2694	50504	1	Bleeder Tube and Container	
*†2684	2184x5	1	Tommy Bar		*†2695	B450	1	Oil Can (De-luxe only)	
*†2685	B458	1	Screw Driver		*†2696	52018	1	Cylinder Head Spanner (De-luxe only)	
*†2686	B459	1	Pliers		*†2697	52019	1	Spanner, $\frac{3}{8}$ in. \times $\frac{1}{4}$ in. Whit. (De-luxe only)	
*†2687	ND151	1	Contact Breaker Spanner		*†2698	52020	1 $\frac{1}{8}$ in. \times $\frac{3}{8}$ in. .. (De-luxe only)	
*†2688	52038	1	Tyre Valve Key		*†2699	52021	1 $\frac{7}{16}$ in. \times $\frac{1}{2}$ in. .. (De-luxe only)	
*†2689	B453	1	.. Pump and Connection		*†2700	ND152	1	Box Spanner, $\frac{3}{8}$ in. \times $\frac{3}{8}$ in. Whit. (De-luxe only)	
†2690	52025	1	Jack—Stevenson Type		†2701	51146	1	Tool Tray (De-luxe only)	

* Denotes items common to Jupiter

Always quote engine, body-frame, part and item numbers in full.

† Denotes items not illustrated