

# Body and Fittings

Item No.	Part No.	Quantity	Description	Notes	Item No.	Part No.	Quantity	Description	Notes
			<b>FRONT AND REAR BUMPER ASSEMBLY</b>						
†3660	55000AS	1	Front Bumper Assembly, complete . . . . .		†3720	53219	2	Adaptor . . . . .	
3661	55571	1	"    "    Bar only . . . . .		†3721	53208	4	Compression Spring—Long . . . . .	
†3662	55501	2	Attachment Bracket Assembly . . . . .		†3722	53215	2	"    "    —Short . . . . .	
†3663	55502	2	Adaptor Plate Assembly . . . . .		†3723	53452	1	Lifting Tube Outer Assembly . . . . .	
3664	55181	4	Bumper Over-rider Assembly . . . . .		†3724	53454	1	Inner Tube—R.H. . . . .	
†3665	55182	2	Spring . . . . .		†3725	53451	1	"    "    —L.H. . . . .	
†3666	FB107/8	2	Bolts— $\frac{7}{16}$ in. $\times$ 1 in. . . . .		†3726	53213	2	Plunger . . . . .	
†3667	55177AS	1	Rear Bumper Assembly—R.H. . . . .		†3727	53214	2	"    Stop Nut . . . . .	
†3668	55178AS	1	"    "    —L.H. . . . .		†3728	ND1407	2	Union Nut . . . . .	
3669	55512	2	"    "    Bar only . . . . .		†3729	53382	1	Hand Rod . . . . .	
†3670	55510	2	Attachment Bracket Assembly . . . . .					<b>FRONT WINGS</b>	
†3671	55511	2	Adaptor Plate Assembly . . . . .		3739	55006	1	Front Wing—R.H. . . . .	
†3672	55500	4	"    "    Bolt . . . . .		3740	55007	1	"    "    —L.H. . . . .	
†3673	55505	2	Rear Bumper Inner Spring . . . . .		†3741	WB104/4B	16	Bolt (Brass) . . . . .	
3674	55506	2	"    "    Outer Spring . . . . .		†3742	1AB56479	1	Front Wing Apron Assembly—R.H. . . . .	
†3675	55507	2	"    "    Tie Spring . . . . .		†3743	1AB56480	1	"    "    "    —L.H. . . . .	
†3676	1.53928	4	"    "    Bracket Stud . . . . .		†3744	1AB56488	1	Apron Bracket Assembly, Front—R.H. . . . .	
†3677	55508	2	Spring Bolt . . . . .		†3745	1AB56489	1	"    "    "    —L.H. . . . .	
3678	55601	1	Front Bumper Valance, complete . . . . .		†3746	1AB56492	1	"    "    "    Centre—R.H. . . . .	
3679	4523x6	4	Bumper Grommet . . . . .		†3747	1AB56493	1	"    "    "    —L.H. . . . .	
			<b>WHEELS AND TYRES</b>		†3748	1AB56497	1	"    "    Lower . . . . .	
3690	53016	5	Road Wheel . . . . .		†3749	WB104/4A	10	Bolt— $\frac{1}{4}$ in. Whit. $\times$ $\frac{1}{2}$ in. . . . .	
3691	53017	5	5.50 $\times$ 16 Tyre . . . . .		†3750	55609	1	Budget Lock—L.H. . . . .	
†3692	53018	5	5.50 $\times$ 16 Tube . . . . .		†3751	55610	1	"    "    —R.H. . . . .	
3693	50804	4	Wheel Cover Cap . . . . .		3752	55558	2	Escutcheon . . . . .	
			<b>BONNET AND FITTINGS</b>					<b>WINDSCREEN</b>	
†3696	55456AS	1	Bonnet and Front Wing Assembly, complete—Less Paint and Trim . . . . .		3760	1B56288	1	Windscreen Bodyframe Assembly . . . . .	
3697	55008	1	Bonnet Panel . . . . .		†3761	55318	1	"    Side Pillar Front—R.H. . . . .	
†3698	55458	1	"    Rear Frame Assembly . . . . .		†3762	55319	1	"    "    "    —L.H. . . . .	
†3699	55468	1	"    Top Frame Assembly . . . . .		†3763	55322	1	"    "    "    Top Rail—R.H. . . . .	
†3700	55480	1	"    Front Cross Member Assembly . . . . .		†3764	55323	1	"    "    "    —L.H. . . . .	
†3701	55149	2	"    Locating Pin . . . . .		†3765	55324	1	"    "    "    Bottom Rail—R.H. . . . .	
†3702	55056	2	Grommet . . . . .		†3766	55325	1	"    "    "    —L.H. . . . .	
†3703	55151	1	Socket Plate—R.H. . . . .		†3767	1B56292	1	"    "    "    Centre Strip—Inner . . . . .	
†3704	55152	1	"    "    —L.H. . . . .		†3768	56236	2	"    "    "    Corner Plate . . . . .	
3705	55039	1	Bonnet Centre Moulding . . . . .		†3769	55107	2	Hood Locating Pin . . . . .	
3706	55093	1	"    Motif . . . . .		†3770	1B56293	1	Windscreen Centre Strip—Outer . . . . .	
†3707	55227	1	"    Hinge Assembly—R.H. . . . .		†3771	1B56298	1	Ball End (Driving Mirror) . . . . .	
†3708	55228	1	"    "    "    —L.H. . . . .		3772	55330	4	Bolt—Frame to Body . . . . .	
†3709	55233	2	"    Hinge Bolt . . . . .					<b>REAR WINGS AND PANELS</b>	
3710	55142	2	"    Catch Assembly . . . . .		3780	55010	1	Rear Wing—R.H. . . . .	
†3711	53384	1	"    Lifting Assembly . . . . .		†3781	55011	1	"    "    —L.H. . . . .	
†3712	53222	1	Strut Assembly—L.H. . . . .		3782	55998	1	Rear Wing Outer Stone Guard—R.H. (Rubber) . . . . .	
†3713	53223	1	"    "    —R.H. . . . .		†3783	55999	1	"    "    "    —L.H. (Rubber) . . . . .	
†3714	53209	2	Tube,—Inner . . . . .		3784	55009	1	Rear Panel Assembly . . . . .	
†3715	53210	2	"    Outer . . . . .		†3785	55555	1	Luggage Trunk Panel Assembly . . . . .	
†3716	53211	2	Plunger Tube . . . . .		†3786	55817	2	"    "    "    Support Bracket . . . . .	
†3717	53216	2	Bush . . . . .		†3787	55813	1	Spare Wheel Carrier Door . . . . .	
†3718	53217	2	Collar . . . . .		†3788	55698	4	Screw—2 BA $\times$ $\frac{3}{8}$ in . . . . .	
†3719	53218	2	Fork End . . . . .		†3789	BWB104/S	30	Brass Bolt— $\frac{1}{4}$ in. Whit. $\times$ $\frac{3}{8}$ in. . . . .	
					†3790	55209	1	Stone Guard Assembly—R.H. . . . .	

\* Denotes items common to Jupiter

† Denotes items not illustrated

Always quote engine, chassis, part and item numbers in full.