

Accelerator Assembly

Item No.	Fig. No.	Part No.	Description	£	s.	d.
410.		6352	Accelerator Pedal complete	7		6
411.		6337	Accelerator Pedal only	2		9
412.		6054x5	Accelerator Rod Roller	1		0
413.		6350	Accelerator Rod Bracket			6
414.		2354x10	Accelerator Pull-off Spring			6
416.		6364	Accelerator Connecting Link	1		0
417.		6365	Accelerator Bell Crank Pivot	1		0
418.		6361	Accelerator Bell Crank Lever	3		6
419.		2742x15	Anti-Rattle Spring			3
420.		6371	Accelerator Ball Connector to Carburetter	2		0

Silencer and Exhaust

440.	AS6179x2	Exhaust Pipe and Silencer	}	only supplied complete	3	0	0
441.	AS6050x1	Double Exhaust Pipe					
442.	6056x1	Exhaust Pipe Fixing Nut (Brass)....					6
443.	6052x4	Support Strap Silencer			1		3
444.	6052x3	Support Strap Clip					6

Steering

450.	AS2802x1S	Steering c'plete (less Steering Wheel)	5	17	6
451a.	R2802x1	Reconditioned Steering complete (less Steering Wheel)	3	7	6
451b.	2805x10/S	Steering Wheel	1	7	3
452.	2805x2	Steering Wheel Fixing Bolt (N.P.) ...	1		6
453.	2802x1AS	Steering Drop Arm only	16		0
454.	2802x1B	Drop Arm Bolt and Nut			4
455a.	2802x1C	Steering Outer Column with Box only	1	15	0
455b.	2802x1D	Steering Inner Column and Worm ...	2		0
455c.	2802x1E	Steering Column Felt Washer (Top)			7
455d.	2802x1F	Steering Cam with Shaft	16		6
455e.	2802x1G	Felt Washer for Cam			2
455f.	2802x1H	Thrust Race and Ball Retainer	3		3
455g.	2802x1J	Steering Box Base Plate	1		6
455h.	2802x1K	Shim for above			2
455j.	2802x1L	Steering Side Plate	1		10
455k.	2802x1M	Shim for above			2
455l.	2802x1N	Bolt for Side and Base Plates			3
455m.	2802x1P	Greaser and Bolt for Side Plate ...	1		9
456.	6022x6	Bolt for Steering Bracket	2		3
457.	ND923	Woodruff Key			2
458.	2805x3	Steering Column Fixing Ball	2		0
459.	2134x9	Steering Column Bracket on Dash (Lower)			6
460.	6055x8	Steering Column Support on Dash (Upper)	2		6