

Fuel System

Item No.	Part No.	Quantity	Description	Notes	Item No.	Part No.	Quantity	Description	Notes
TANK AND FITTINGS					ACCELERATOR PEDAL ASSEMBLY				
3216	53240AS	1	Fuel Tank, complete		3270	53406	1	Accelerator Pedal Assembly	
3217	53252	1	" Feed Pipe Assembly		†3271	50939	1	" Lever	
3218	53256	1	Elbow Sealing Washer—Fibre		†3272	52111	1	Roller Stud	
3219	53256/A	as reqd.	" Shim		†3273	50490	1	Lever Boss	
†3220	53261	2	Felt Packing—Top		†3274	52063	1	Spacer	
†3221	53262	2	" —Bottom		†3275	50941	1	Accelerator Roller	
†3222	53263	2	Strap Assembly, complete		†3276	52081	1	" Pedal Spring	
†3223	53267	2	Tension Bar		†3277	8507	1	" " Assembly	
†3224	NN205K	2	Locknut		†3278	8508	1	" " Cradle	
3225	55736	1	Monza Type Filler Cap		†3279	8511	1	" Pedal	
3226	55439	1	Filler Adaptor Assembly		†3280	8515	2	Link	
3227	53441	1	Sealing Washer—Small		†3281	8516	2	" Pin	
3228	53440	1	" " —Large		†3282	8518	1	Operating Lever	
3229	55746	1	Connector Hose		†3283	7585	1	Return Spring	
3230	55747	2	Jubilee Clips		†3284	8519	2	Pivot Pin	
3231	53160	1	Tank Petrol Gauge Unit		†3285	8520	1	Cable Barrel Nipple	
3232	53160/A	1	Tank Unit Gasket						
3233	50991	6	Petrol Tank Unit Screws—BA						
PIPES AND FITTINGS					THROTTLE CONTROLS				
3238	1.53889	1	Pipe Long—Tank to Pump		3290	53099	1	Accelerator Cable, complete—R.H.D.	
3239	1A53871	1	Feed Pipe—Pump to Filter		†3291	53100	1	" " Outer—R.H.D.	
3240	1A53884	1	Pipe—Filter to "T" Piece		†3292	53665	1	" " " —L.H.D.	
3241	1A53885	1	"T" Piece		†3293	53101	1	" " Inner—R.H.D.	
3242	1A53886	1	Pipe "T" Piece to Flexible Pipe—R.H.		†3294	53664	1	" " " —L.H.D.	
3243	1A53887	1	" " " " —L.H.		3295	1.53709	1	Throttle Rod Clamp Bolt—R.H.D.	
3244	6215x13	2	Flexible Pipe						
†3245	52210	7	Nipple		3300	1.53732	1	Carburettor—N/S	
3246	52209	7	Union Nut		3301	1.53733	1	" —O/S	
3247	53251	1	Elbow—Feed Pipe		†3302	1.53732R	1	Reconditioned Carburettor—N/S	
†3248	53570	8	Strip—Location Strip		†3303	1.53733R	1	" " —O/S	
†3249	1.53870	2	Clip—Petrol Pipe Support at Radiator Bolt		†3304	09865	2	Air Regulating Screw	
†3250	2331x14	12	"P" Clips		†3305	09846	2	Spring for Air Regulating Screw	
3251	ND392	2	Union Nut		†3306	07860/120	2	Progression Jet	
†3252	ND392A	2	Olive		†3307	07723	2	Strangler Flap (assd. complete)	
					†3308	014303	2	" Spindle and Lever (assd. complete)	
					3309	06099	2	Filter Banjo	
					3310	06101	4	Fibre Washer for Filter Banjo	
3255	1.53814	1	PETROL PUMP		3311	06098	2	Filter Plug	
†3256	FB/105/5	2	Petrol Pump (SU PP36L)		3312	06100	2	" Gauze	
					†3313	07864	2	Needle Seating (assd. complete)—1.5 mm.	
					†3314	09619	2	Washer for Needle Seating	
					†3315	08898	2	Float	
†3260	1.53795	2	AIR CLEANER AND FITTINGS		†3316	16605/120	2	Main Jet	
3261	1.53866	2	Air Cleaner, complete with Tubes and Clips		†3317	16620/65	2	Compensating Jet	
3262	1.53864	2	" " Tube		†3318	06798/45	2	Slow Running Jet	
3263	ND142	4	" " Clips		†3319	07928	2	Screw over Capacity Tube	
					†3320	09770	2	Emulsion Block (assd. complete)	
					†3321	08363	2	Gasket for Emulsion Block	
†3266	53194	1	CHOKER CONTROL						
			Choke Control Cable, complete						

* Denotes items common to Jupiter

† Denotes items not illustrated

Always quote engine, chassis, part and item numbers in full.